## M2110 Series Smart Gauge

## **Pressure, Flow or Level Versions Available**



Meriam's M2110 Series Smart Gauge is back by popular demand! It features Meriam's new Embedded Pressure Instrument (EPI) for the latest technology while retaining the enclosure and user interface from the original design. The large display, flexible mounting (Panel, Pipe or Bench top) and power options (24 VDC, Battery or AC) make it the ideal gauge for almost any application. The M2110 features NIST traceable accuracy of  $\pm 0.05\%$  F.S., independent of temperature effect, at a reasonable price.

Pressure ranges are now available to measure differential, gauge, compound gauge and absolute for a variety of gases and liquids. The display can be read out in any of the selectable engineering units or be scaled for flow rate or tank level depending on model selected.



### **Pressure Accuracy**

Accuracy:  $\pm$  0.05% FS. No temperature effect from -4° to 122° F (-20° to +50° C).

### Engineering Units M2110P (Pressure)

mmHg, PSI, in Hg, mbar, Bar, kPA, Inches H2O (Select 20° C, 4° C or 60° F), Kg/cm2, cmH20 and user defined.

### M2110F (Flow) & M2110L (Level)

gallons, pounds, cubic feet, liters, percent, kilograms, cubic meters, Inches H2O and user defined.

### **Damping Rates**

Exponential damping with user selectable time constant from 0.1 to 50 seconds.



An adjustable damping feature minimizes the effects of pulsating pressures. SPDT relays on AC powered units or the 4-20mA output on 24VDC units make the M2110 an ideal choice for many control and recording functions. Both models also include RS232C communications for additional control and data logging capabilities.

### **Media Compatibility**

DN: Non-isolated differential sensor for clean, dry, non-corrosive gases. DI: Isolated differential sensor for fluids compatible with 316L SS and Viton.

GI, CI or AI: Isolated gauge or absolute sensor for fluids compatible with 316L SS.

### **Pressure Limits**

DN: 2x F.S. when pressurized on high side only and 150 PSI static when applied to both sides simultaneously. DI: Common mode pressure 1,000 PSI, P1 (Hi) only is 3x F.S., P2 (Lo) only is 3x F.S. or 150 PSI - whichever is less. GI, CI and AI: 2x F.S.

### (Battery Models)

User selectable shut-off. Programmable at 1, 2, 5, 10, 15, 25 minutes.

### Lockout

Two digit code to prevent inadvertent resetting of configurations.

## Adjustable Deadband (SPDT Relay Models)

Value can be set to 0, 0.1, 0.2, 0.5, 1, 2, 5 and 10% of F.S.



Meriam Process Technologies 10920 Madison Avenue, Cleveland, OH 44102

## **Rely On The Trusted Leader In Measurement And Calibration**

# M2110 Series Smart Gauge

Accuracy

Pressure: + 0.05% FS.

Analog Output: ± 0.05% FS. + 3 Counts

Operating: -4° F to 122° F (-20° C to 50° C)

(DN) Differential, Non-Isolated, Dry 0-10", 0-28", 0-200", 0-415", 0-2,000" H2O

0-5, 0-15, 0-30, 0-100, 0-300, 0-500 PSID

-15 to 15, -15 to 30, -15 to 50, -15 to 100,

0-15, 0-30, 0-50, 0-100, 0-300, 0-500, 0-1,000,

(DI) Differential, Isolated, Wet

(CI) Compound Gauge, Isolated

0-17, 0-38, 0-100, 0-1,000 PSIA

Temperature Specifications Storage: -40° F to 140° F (-40° C to 60° C)

Pressure Ranges

(GI) Gauge, Isolated

(AI) Absolute, Isolated

0-3,000 PSIG

Zero Drift: ± 0.015% FS. - Zero prior to use eliminates this effect.

## **Technical Specifications**

### Enclosure

4 pounds. 1/4" DIN (3.8"x3.8"x6.5") aluminum enclosure with epoxy finish.

Standard unit is NEMA 4X on front panel only. Battery and 4-20mA units are NEMA 4X throughout.

### Keypad

Sealed membrane type with 4 dome contact style buttons.

### Display

4.5 digit LCD, 0.6" high (15.24 mm) LED Backlight

### **Power Options**

Standard unit has selectable 110 VAC 50/60 HZ, 240 VAC 50/60 HZ or 24 VDC power, 24 VDC power for current outputs Lithium Battery (2 - "D" Cells on battery board)

### Wetted Parts

DN: 316L S.S., Brass, Viton DI: 316L S.S., Viton O-rings CI, GI and AI: 316L S.S.

### Connections

1/8" FNPT DI with flushing ports: 5/16 - 24 SAE/MS J1926 flushing ports with 316L SS plugs (2 each optional)



DN or DI Standard Manifold

### **Ordering Information**

Model No & Description

M2110P: (Specify Range) - (Mounting Option) - (Power Option) M2110F: (Specify Range) - (Mounting Option) - (Power Option) M2110L: (Specify Range) - (Mounting Option) - (Power Option)

Mounting Options

01 = Panel Mount 02 = 2" Pipe Mount 03 = Portable Bench Top

All Models Include: NIST Cert and Data



DI - Option 4 Port Manifold with Flushing Ports



-15 to 300, -15 to 500, -15 to 1,000, -15 to 3,000 PSIG

GI, CI, or AI Standard Manifold

### Power Options

1 = 110 VAC, 240 VAC, 24 VDC/RS232C, 2 SPDT Relays 2 = Lithium Batteries with No Outputs - NEMA 4X 3 = 24 VDC/4-20mA, RS232C - NEMA 4X 4 = 1-5 Volt Output

Example: M2110P-DN0028-03-1 Pressure Unit, 0-28" H2O, Portable, User Configurable



Meriam Process Technologies 10920 Madison Avenue, Cleveland, OH 44102