

LABCELL LTD

ENGINE TEST INSTRUMENTATION


ECM dashCAN, dashCAN+ Remote CAN Display



Now dashCAN+ available with six programmable analogue outputs



ECM's dashCAN and dashCAN+ are remote displays for ECM's CAN modules (ex. LambdaCAN). Simply attach dashCAN or dashCAN+ to the CAN bus and any two parameters from the network can be displayed. For dashCAN+, any six parameters also can be converted to analog output signals. Perfect for dashboard use, dashCAN and dashCAN+ use tall (13mm), 15-segment LED digits for easy viewing at all cabin temperatures and lighting conditions. The module, display parameters, display averaging rate, LED intensity, and for dashCAN+, analog output parameters, are programmable via the front-panel buttons. Multiple dashCANs and dashCAN+s can be attached to the CAN bus. ECM's dashCAN and dashCAN+ are superb additions to your ECM CAN network.



LABCELL LTD

FOUR MARKS, ALTON, HAMPSHIRE GU34 5PZ
TEL: ++44 (0)1420 568150 FAX: ++44 (0)1420 568151
e: mail@labcell.com www.labcell.com







Easily tap into multi-channel Lambda and NOx CAN networks such as this.